

TECH DATA SHEET

ULTRA BUFFING SYSTEM SWIRL REMOVER

DESCRIPTION:

Swirl Remover is designed to remove swirls from both fresh and cured paint surfaces, and leave the highest gloss finish. If the swirls are heavy and/or cured, the best results are achieved by compounding, polishing and then using Swirl Remover.

DIRECTIONS:

- 1. Shake well before using.
- Apply a 1" (25 mm) dab of Swirl Remover to a 2'x 2' (.6m x .6m) section and spread with the polish pad. Buff at 1400 to 2800 rpm with wool or 1200 to 1600 rpm with foam.
- 3. Buff until the product is mostly gone. Always ensure finishing strokes are front to back.
- 4. Wipe surface with a Presta Micro Fiber Cloth (# 800135).

RECOMMENDED PAD:

- Compound first with Presta Ultra Cutting Crème™ Light (#133432 or #133401). Use a Presta Yellow Wool Pad.
- After compounding, use Ultra Swirl Remover and a Presta Blue Foam or Wool Pad.

FEATURES & BENEFITS

Unique micro-abrasive formula	Removes swirls from fresh and cured paint surfaces
Consistently performing product	Produces a clean, high-gloss finish that doesn't wash away
Contains no fillers, waxes or silicones	Body-shop safe and can be used on freshly cured paints

PACKAGE SIZES:

Quart bottlesPart # 133632Gallon containersPart # 133601



TECH DATA SHEET

PRODUCT FAQ'S:

Q1: Is Swirl Remover body shop safe?

A1: Yes, Swirl Remover is body shop safe and contains not silicone, wax, or fillers.

Q2: Will Swirl Remover remove sand scratches?

A2: The product is not designed to remove sand scratches but could possibly remove light surface damage or car wash scratches.

Q3: How does Swirl Remover remove swirls and holograms?

A3: Swirl Remover uses a micro abrasive that polishes and removes micro scratches and holograms left from polishing and compounding in previous steps.

Q4: How do I know what Presta pad to use with Swirl Remover?

A4: Presta products have a color coded banner behind the Presta logo on each bottle that matches the color of the buffing pad that should be used.

Q5: Should Swirl Remover be used with a wool or foam pad?

A5: Swirl Remover can be used with either wool or foam and is technician preference what they prefer to use.