

# Swirl Remover 5384

Ultimate Finish System<sup>™</sup> Swirl Remover easily removes fine swirl marks and leaves a high gloss finish with minimal effort. Swirl Remover improves color, clarity and shine, leaving a polished, showroom finish. Though safe on all paints, Swirl Remover is specially formulated for prime results on darker colors. For best results, use with Transtar's Gold Foam Pad 5292.



Mix Ratio Mix Ratio: Ready to use



## Surface Prep & Application

Wipe surface clean with a clean, dry, non-abrasive cloth. Do not apply in direct sunlight. Shake container well before use. Apply a 1.25" wide by 6" long ribbon (for every 2' x 2' area) of Swirl Remover. For best results, use sparingly. Spread with pad to minimize sling. Using a buffer at low speed (1000-1200 rpm), work material in a circular overlapping motion with Swirl Remover Gold Foam Pad 5292 while applying uniform pressure. As shine appears, reduce buffer pressure. Continue buffing to desired gloss. Finish by removing any residue with clean microfiber cloth.



### **Product Specifications**

Color.....White Shelf life.....3 years Size.....Quart

### Regulatory

-	
Category	Automotive rubbing or polishing coumpound
VOC Conte	nt<13% by weight



### **Limitations & Precautions**

- Visit www.tat-co.com to assure use of the most current instructions and TDS on this product.
- See website (www.tat-co.com) for this document in other languages. (Vea el web site para este documento en español. Voir le site web pour ce document en français.)
- For use only by professional, trained painters. Not for sale to or use by the general public.

#### LIMITED WARRANTY

The successful performance of this product is dependent on many factors beyond our control. Results are dependent upon the skill of the operator. This product is manufactured to meet the highest level of consistency and quality for the intended use. Transtar Autobody Technologies, Inc. warrants that its products meet the specifications which it sets for them. Should this product be proven to be off-specification within shelf life as stated in this datasheet, Transtar Autobody Technologies, Inc. will, at its sole discretion, either replace the product or issue credit for the original purchase price of the product. The replacement or refund shall be the buyer's sole remedy and Transtar Autobody Technologies, Inc. and its affiliates MAKE NO OTHER WARRANTY OR GUARANTEE, EXPRESS OR IMPLIED, INCLUDING MERCHANTABILITY, DESIGN COMPATIBILITY AND FITNESS FOR A PARTICULAR PURPOSE. LABOR OR COST OF LABOR AND OTHER INCIDENTAL AND/OR CONSEQUENTIAL DAMAGES ARE SPECIFICALLY EXCLUDED. The technical data contained herein are true and accurate to the best of our knowledge. Published technical data and instructions are subject to change without prior notice.